









# Marid Lancers / Marid Sahar Assembly Instructions


## READ THIS FIRST

**BEFORE ASSEMBLING YOUR MODEL KIT PLEASE READ THROUGH THE INSTRUCTIONS IN THIS BOOKLET CAREFULLY.** A pair of plastic cutters is required to remove the plastic components from their frame. We recommend using a mouldline remover to clean up the parts. Plastic glue is required to assemble your model.

## SYMBOL EXPLANATION


- |   |  |  |
|---|--|--|
|  Special Instruction - Please read |  Do not glue the components |  Rotate part        |
|  Variant assembly                  |  Detail view                |  Glue the component |
|  Stage complete                    |  Repeat process             |  |


### You will need:



Scan here:  
For the extensive instructions and the latest update of the instructions.

### What you get:








-  Make sure to dry fit parts before gluing.  
Part numbers with a "ML" originate from the 20260608SOKILANCR41 sprue.




**Customizability:**  
◆ No customizability.

# Marid Lancers / Marid Sahar



## Pose 1 - Variations and Marid Sahar Leader



5 **Marid Lancers**



**Marid Sahar**



Marid Sahar Leader




Marid Sahar Troop




Pose 2 - Variations and Marid Lancers Leader

1




2




3



4





5




6

Marid Lancers

Marid Sahar



Leader Parts	
2ML	4ML 3ML
Left Arm	
1ML	
Shoulderpads	
5ML	6ML




Marid Lancers Leader


Marid Lancers Troop




1




2



3





4



5

Marid Lancers



Marid Sahar

